



Note: Lifting loops are for plant use and ground movement only and are not engineered for overhead use.
Extreme caution must be used when lifting planter from lifting loops higher than 12" from ground.

R 3617 Rectangular Planter	Width x Length x Height	weight
	36" x 36" x 17"	430 lbs